


SDK

ML8088sE.



- **arm-none-eabi (GNU ARM)** – ;
- **RVCT 4.0** ARM Development Studio 5 (DS-5) - -
ARM.

1. STA8088_GNSSAPP
2. API
- 3.

- : STA8088CFG
- : ARM946
- : 52, 104, 208
- - : 2
- : 2 UART, 1 USB/UART
-